


Woodburning Safety

Safety Tips & Tricks

- Don't touch the metal when machine is on!
- Keep your burner away from flammable stuff.
- Tie back loose hanging hair, jewelry, headphones, etc.
- Work on a hard, sturdy surface [ex: table or desk... no need to burn holes in the couch. Or your leg.]
- Secure the stand to the table. [no holes in the carpet either]
- Always place your burner on the stand when not in use.
- Turn burner off any time you leave the table. Unplug when leaving the room.
- Use metal pliers to gently remove hot tips or insert cool tips into a hot burner. Place hot tips in a heat-safe dish to cool. If a tip resists going in: STOP, back up, and try again.
- Only burn on dry, well-seasoned, non-toxic wood that has not been chemically treated. When burning things other than wood (like fabric, bone, cork...), make sure to they are free of any chemical treatments, glues, stains, finishes, etc.
- Teach kids safety around pyrography tools. Keep hot tools out of their reach.

Safety Tools & Gear

- **Adjustable drawing table:**
Helps keep heat from fingers and face. Also helps with artist posture.
- **Leather gloves, rubber finger guards, finger heat shields, or thick cork grips:**
Keeps fingers from getting too hot.
- **P95 Mask:**
For lung protection from smoke and sanding.
- **Fan:**
Helps move smoke and heat away from face and fingers. Better yet, get a fan with an activated charcoal filter to clean smoke out of the air as it pulls it away from you.
- **Air purifier:**
Cleans smoke and particulates from burning and sanding out of the air.



[BURN SAVVY]